

## Product Manual

Revision date: 18/May/2017

# Cow Blue-tongue virus (BTV) ELISA Kit

**Catalog No.:** BTA14713

**Range:** Qualitative

**Sensitivity:** Qualitative

**Storage:** Store at 2-8°C for 6 months.

**Application:** For qualitative detection of BTV in Cow Serum, Plasma and other biological fluids.

**Introduction:** Bluetongue disease is a non-contagious, insect-borne, viral disease of ruminants, mainly sheep and less frequently cattle, goats, buffalo, deer, dromedaries, and antelope. It is caused by the Bluetongue virus (BTV). The virus is transmitted by the midge *Culicoides imicola*, *Culicoides variipennis*, and other culicoids. In sheep, BTV causes an acute disease with high morbidity and mortality. BTV also infects goats, cattle and other domestic animals as well as wild ruminants (for example, blesbuck, white-tailed deer, elk, and pronghorn antelope).

### Principle of the Assay

This kit is based on sandwich enzyme-linked immune-sorbent assay technology. A 96 well plate has been pre-coated with an antibody specific to BTV. Controls or test samples are added to the appropriate wells and incubated. Free components are washed away with wash buffer. HRP conjugated detection reagent is added to the wells. TMB substrate is used to visualize HRP enzymatic reaction. TMB is catalyzed by HRP to produce a blue color product that changes into yellow after adding acidic stop solution. The intensity of the color yellow is proportional to the BTV amount bound on the plate. The O.D. absorbance is measured spectrophotometrically at 450 nm in a microplate reader, and the presence of BTV can be determined.

### Kit components

1. One pre-coated 96 well plate
2. Positive Control: 0.5 ml
3. Negative Control: 0.5 ml
4. Wash buffer (30×): 20 ml. Dilution: 1:30
5. Sample diluent buffer: 6 ml
6. HRP Conjugate Reagent (RTU): 6 ml
7. Stop solution: 6 ml
8. TMB substrate A: 6 ml
9. TMB substrate B: 6 ml
10. Plate sealer: 2
11. Hermetic bag: 1
3. Precision pipette and disposable pipette tips
4. Automated plate washer
5. ELISA shaker
6. 1.5 ml tubes to prepare standard/sample dilutions
7. Plate cover
8. Absorbent filter papers
9. 100 ml and 1 L volume graduated cylinders

### Material Required But Not Provided

1. 37°C incubator
2. Microplate reader (wavelength: 450 nm)

# Product Manual

Revision date: 18/May/2017

## Protocol

### A. Preparation of sample and reagents

#### A. Sample

Isolate the test samples soon after collecting and analyze immediately at 1:5 dilution (within 2 hours) or aliquot and store at -20°C

- **Serum:** should be collected into a serum separator tube. Coagulate the blood at room temperature (~2 hr) or overnight at 4°C. Centrifuge at approximately 1000 × g for 20 min. Analyze the serum immediately or aliquot and store at -20°C or -80°C.
- **Plasma:** plasma using citrate or EDTA as an anticoagulant. Centrifuge for 15 minutes at 1000 x g within 30 minutes of collection. Assay immediately or aliquot and store at -20°C. Avoid hemolysis and high cholesterol samples.
- **Other biological fluids:** at approximately 1000 × g for 20 min to remove precipitant. Analyze immediately or aliquot and store at -20°C or -80°C.

#### Note:

- » Coagulate blood samples completely, centrifuge, and avoid hemolysis and precipitant.
- » NaN<sub>3</sub> cannot be used as test sample preservative, since it inhibits HRP.
- » Store samples undiluted. Once ready to analyze, thaw samples and dilute 1:5.

#### 1. Wash buffer

Dilute the concentrated Wash buffer 30-fold (1/30) with distilled water (i.e. add 20 ml of concentrated wash buffer into 580 ml of distilled water).

#### 2. Assay Procedure

Equilibrate the kit components and samples to room temperature prior to use. It is recommended to plot a standard curve for each test.

1. Set positive/negative, test sample and control (zero) wells on the pre-coated plate respectively and record their positions.
2. Aliquot 50 µl of the negative and positive controls into the set wells. Leave one well as the control (zero) blank well.
3. Aliquot 50 µl of appropriately diluted sample into the test sample wells. Samples should be diluted 1:5. Add the solution at the bottom without touching the side walls of the well. Shake the plate mildly to mix the contents.
4. Seal the plate with a cover and incubate at 37°C for 30 min.
5. Remove the cover and discard the plate contents by tapping the plate on absorbent filter papers or other absorbent material.
6. Wash the plate 5 times with wash buffer. Do not let the wells completely dry at any time.

**Manual Washing:** Discard the solution without touching the side walls. Tap the plate on absorbent paper or other absorbent material. Fill each well completely with wash buffer and incubate on an ELISA shaker for 2 min. Discard the contents and tap the plate on absorbent filter papers or other absorbent material. Repeat this procedure five times.

**Automated Washing:** Discard the solution in all wells and wash the plate five times with Wash buffer (overfilling the wells with the buffer). After the final wash invert the plate and tap on absorbent filter papers or other absorbent material. It is recommended that the washer be set for a soaking time of 1 min.

1. Add 50 µl of HRP conjugate reagent into each well (except control well). Add the solution at the bottom of each well without touching the side wall.
2. Seal the plate with a cover and incubate at 37°C for 30 min.

## Product Manual

Revision date: 18/May/2017

---

1. Remove the cover and repeat the aspiration/wash process 5 times as explained in step 7.
2. Aliquot 50  $\mu$ l of TMB Substrate A into each well and 50  $\mu$ l of TMB Substrate B. Vortex the plate gently on an ELISA shaker for 30 seconds (Or shake gently by hand for 30 seconds). Cover the plate and incubate at 37°C for 15 min. Avoid exposure to light.
3. Add 50  $\mu$ l of Stop solution into each well. There should be a color change to yellow. Gently tap the plate to ensure thorough mixing.
4. Ensure that there are no fingerprints or water on the bottom of the plate, and that the fluid in the wells is free of bubbles. Measure the absorbance at 450 nm immediately.

### 5. Analysis

6. Test effectiveness: the average value of positive control  $\geq 1.00$ ; the average value of negative control  $\leq 0.10$ .
7. The critical value (CUT OFF) calculation: critical value = the average value of negative control + 0.15
8. Negative Result: if the OD value < CUT OFF, the sample is BTV negative.
9. Positive Result: if the OD value  $\geq$  CUT OFF, the sample is BTV positive.

### 10. Precautions

11. Before using the kit, centrifuge the tubes to bring down the contents trapped in the lid.
12. Avoid foaming or bubbles when mixing or reconstituting components.
13. Wash buffer may crystallize and separate. If this happens, please heat the tube to dissolve.
14. It is recommended measuring each controls and samples in duplicate or triplicate.
15. Do NOT let the plate dry out completely as this will inactivate the biological material on the plate.
16. Ensure plates are properly sealed or covered during incubation steps.
17. Complete removal of all solutions and buffers during wash steps is necessary for accurate measurement readings.
18. Do not reuse pipette tips and tubes to avoid cross contamination.
19. Do not use expired components or components from a different kit.
20. Store the TMB substrate B in the dark and to avoid edge effect due to temperature difference during plate incubation it is recommended to equilibrate the TMB substrates for 30 min at room temperature prior to use. Aspirate the dosage needed with